

NESPRESSOVERTUO POP

Utilizzo della macchina :

- girare la manopola nera posta sulla calotta della macchina fino al simbolo “lucchetto aperto”
- la calotta si aprirà per inserire la cialda nell’apposito scomparto
- chiudere la calotta spingendola verso il basso e girare la manopola verso il simbolo “lucchetto chiuso”
- per erogare il caffè cliccare il pulsante simbolo “tazza” sulla sommità della calotta, attendere l’uscita del caffè e cliccarlo nuovamente il pulsante per terminare l’erogazione.

La capsula viene espulsa automaticamente dopo l'erogazione.

Controllare che nel serbatoio posto sul retro della macchina ci sia acqua, altrimenti alzare il coperchio trasparente e riempirlo di acqua potabile.

Buon Caffè!

Using the coffee machine:

- turn the black knob on the top of the machine to the "open padlock" symbol
- the cover will open to insert the pod into the pod compartment
- close the cap by pushing it down and turn the knob to the "padlock closed" symbol
- to brew coffee click the "cup" symbol button on the top of the machine, wait for the coffee to come out and click the button again to finish brewing.

The capsule is automatically ejected after brewing.

Check if there is water in the tank at the back of the machine, if not, lift the transparent lid and fill it with drinking water.

Enjoy your coffee!